

Tilmaamaha Baaritaanka Radon

1. Fur kiishka xaashida ah oo ka soosaar caaga madow. Ha furin caaga.
2. Ku qor lambarka baarkoodhka foomka baaritaanka ee buluugga ah. Lambarka baarkoodhka wuxuu ku qoran yahay dhinaca caaga.
3. Ku qor taariikhda bilawga foomka baaritaanka ee buluugga ah iyo gadaasha kaarka Waxa Socda Baaritaanka Radon (Radon Test in Progress). **Heli maysid natiijo tijaabo haddii aysan jirin taariikh bilaw oo qoran.**
4. Dhig caaga oo saar kaarka Waxa Socda Tijaabada Radon meel caadi ah, sida qolka hurdada, qolka fadhiga, qolka cuntada, xafiiska, ama qolka ciyaarta. Caaga waa in la dhigo meel ugu yaraan 20 inji u jirta dhulka ugu yaraana saddex fuudh u jirta albaabada dibadda iyo daaqadaha. U jirsii walxaha kale ugu yaraan 4 inji caaga muddada tijaabadu socoto.
5. Buuxi inta soo hartay ee foomka baaritaanka ee buluugga ah oo isaga iyo caaga meel wada dhig.
6. Dhammaadka muddada tijaabinta, ku qor taariikhda dhammaadka foomka tijaabinta ee buluugga ah iyo gadaasha kaarka Waxa Socda Tijaabada Radon. **Heli maysid natiijo tijaabo haddii aysan jirin taariikh dhammaad oo qoran.**
7. Ku soo celi caaga, foomka tijaabinta ee buluugga ah ee la buuxiyey iyo kaarka Waxa Socda Tijaabada Radon ee la buuxiyey RSSI si loo lafaguro.

Hubi in:

- Aad bilawdo tijaabada isla marka aad hesho agabka tijaabada.
- Dhig caaga meel guriga ka mid ah oo caadi ah oo ugu hoosaysa, sida qolka fadhiga ee dabaqa koowaad ama qolka qoyska ee dhulka hoostiisa.
- Tijaabi ugu yaraan 3 bilood, laakiin waxa fiican 6 ilaa 12 bilood.
- Ku dar xilliga jiilaalka muddada tijaabinta.
- Isticmaal nidaamyadaada kulaylinta iyo qaboojinta, oo ay ku jiraan furitaanka ama xiritaanka daaqadaha iyo albaabada, sida aad caadiyan yeesho.
- Qallayl ku ilaali caaga.

Ha samayn:

- Ha furin caaga madow ama ha ka goyn summadda cad caaga kaanistarta.
- Ha dhigin caaga xamaamka, kijada, qolka dhar-maydhka, marinka, kabarka, ama qolka makaanikada. Ha dhigin caaga dhismaha dhulka hoostiisa **ilaa** ay meel caadi ah ay tahay.
- Ha dhaqaajin ama arbushin caaga muddada tijaabada.
- Ha isku dayin inaad saamayso natiijooyinka.

Daawo fiidyow tallaabo-tallaabo ah oo muujinaya sida loo dhammaystiro tijaabadaada [HealthVermont.gov/radon](https://www.healthvermont.gov/radon) (Ingiriisi ku qoran).

Ku soo celi foomka la buuxiyey iyo caaga:

RSSI

6312 Oakton Street

Morton Grove, IL 60053

Su'aalo ma qabtaa? La xiriir Barnaamijka Radon:

taleefanka: 1-800-439-8550

iimeylka: radon@vermont.gov

websiteska: HealthVermont.gov/radon (Ingiriisi ku qoran)

Radon Test Instructions

1. Open the foil pouch and remove the black canister. Do not open the canister.
2. Write the barcode number on the blue testing form. The barcode number is printed on the side of the canister.
3. Write the start date on the blue testing form and on the back of the Radon Test in Progress card. **You will not get a test result if there is no start date written down.**
4. Place the canister on top of the Radon Test in Progress card in a living space, like a bedroom, living room, dining room, office, or playroom. The canister should be placed at least 20 inches from the floor and at least three feet from exterior doors and windows. Keep other objects at least 4 inches away from the canister during the test.
5. Fill out the rest of the blue testing form and keep it with the canister.
6. At the end of the testing period, write the end date on the blue testing form and on the back of the Radon Test in Progress card. **You will not get a test result if there is no end date written down.**
7. Return the canister, completed blue testing form and completed Radon Test in Progress card to RSSI for analysis.

Make sure to:

- Start the test as soon as you get the test kit.
- Place the canister in the lowest living area of your home, like a first floor living room or basement family room.
- Test for at least 3 months, but ideally for 6 to 12 months.
- Include a winter season in the testing period.
- Use your heating and cooling systems, including opening or closing windows and doors, as you normally would.
- Keep the canister dry.

Do not:

- Do not open the black canister or remove the white label from the canister.
- Do not put the canister in a bathroom, kitchen, laundry room, hallway, closet, or mechanical room. Do not put the canister in a basement *unless* it contains living space.
- Do not move or disturb the canister during the test.
- Do not try to manipulate the results.

Watch a [step-by-step video of how to complete your radon test at HealthVermont.gov/radon](https://www.healthvermont.gov/radon) (in English).

Return completed form and canister to:

RSSI
6312 Oakton Street
Morton Grove, IL 60053

Questions? Contact the Radon Program:
phone: 1-800-439-8550
e-mail: radon@vermont.gov
website: HealthVermont.gov/radon (in English)